



FC CREAMSD2 - OROSHOCK



DESCRIPTION	OROSHOCK personalization system FC CREAMSD2 transfer paper + AU CRT OROSL (gold foil) or AU CRT ARGSL (silver foil)	
TECHNICAL DATA	FC CREAMSD2 is made of a 120 g/m ² paper liner , thickness 130 µm and a 16 g/m ² polyolefin , thickness 20 µm.	
EQUIPMENT	B/W or color laser printer or copy machine + heat press	
SUITABLE FOR	Covers and folders in natural or artificial leather, balacron theses, presentations, binders, notebooks, menus, books and more.	FC CREAMSD2 is a transfer paper that releases only toner , ideal for printers with high temperature fusers. No need to separate film from liner.

FEATURES

INSTRUCTIONS	 1 Insert the transfer paper in the printer's by-pass or drawer and set to "extra heavy 1" printing mode (121-188 g/m²). Multicopy print. Print on the glossy side in mirror mode and intense color setting.
	 2 Place the printed side of the transfer paper on the folder.
	 3 Protect the transfer with two layers of polyester cloth (MA STUOI 04). Then: Manual or pneumatic press: 130°C for 80" or 140°C for 70" - pressure medium/3,5atm
	 4 Remove the folder from the press and peel off paper before it cools down completely. N.B.: Before next step wait until the folder is perfectly cold.
	 5 Place the printed folder on the press and cover with gold (AU CRT OROSL) or silver foil (AU CRT ARGSL) with the internal side (grey colored) of the roll on the print.
	 6 Protect with the soft silicone pad (MA STUOI GB80). N.B.: The pad must be cold. Then: Manual or pneumatic press: 130°C for 70" or 140°C for 60" - pressure high/5atm
	 7 Remove the metal foil, either warm or cold. Any residual gold or silver can be rubbed off with a cloth soaked in methylated spirit. Use silicon spray to shine the folder.

WARNINGS	In case of continuous applications it may be necessary to lower pressing time a few seconds. For further information contact your dealer.	Store in a cool dry place. Do not expose to direct sunlight. If properly stored the product will maintain its features for at least 2 years.	STORAGE
----------	---	---	---------

The instructions on this sheet are merely indicative and contain details concerning tests carried out in our laboratories with our equipment. Do your own testing. The manufacturer will replace defective material but is not responsible for any damage resulting from incorrect use.

* *Also available in 100/A4 packs or 100/ A4+ (21cm x 30,5cm) packs

SHOCKLINE
about your transfer paper

T. +39 (0)875 751194 - F. +39 (0)875 751329
info@shockline.it - skype shock.line
www.shockline.it

code